

Several commonly used fields in version 3.7.6 have been moved to a new location in version 4. Below is a partial list of those fields and their new locations.

Old location	New location	Comment
General:flyCState	Controller:ctrl_mode mr_controller:ctrl_mode	Not the same values as Controller:ctrl_mode
General:flycCommand	OsdData:flycCommand	
General:flightAction	OsdData:flightAction	
General:nonGPSCause	OsdData:nonGPSCause	
General:compassError	OsdData:compassError	
General:connectedToRC	OsdData:connectedToRC	
General:lowVoltage	OsdData:lowVoltage	
General:ModeSwitch	OsdData:ModeSwitch	
General:gpsUsed	OsdData:gpsUsed	
General:visionUsed	OsdData:visionUsed	
General:notEnoughForce	OsdData:notEnoughForce	
General:Tick#	Clock:Tick#	
General:offSetTime	Clock:offsetTime	
General:relativeHeight	IMU:relativeHeight OsdData:relativeHeight	IMU:press - IMU:press@launch
General:vpsHeight	OsdData:vpsHeight	
General:navHealth	OsdData:navHealth Controller:navHealth Mr_Controller:navHealth	
General:flightTime	OsdData:flightTime	